

P.O. Box 568, Southport, QLD 4215
PH 1300 887 077, Fax 07 55026808, Mob 0403 570499

2. The deck panel must be positioned accurately within the tack free time of the adhesive, and pressed firmly in place to avoid air entrapment.
3. Clamps, weights, or screws (removable), can also be used to secure the panel while the adhesive sets.

This information has been given in good faith and with the knowledge best known at the time of documentation. It is recommended that due to the differences found in glass that a sample be made before proceeding with the entire job.