

P.O. Box 568, Southport, QLD 4215
PH 1300 887 077, Fax 07 55026808, Mob 0403 570499

INSTRUCTIONS FOR BEDDING AND SEALING FITTINGS AND HARDWARE

PREPARATION OF SUBSTRATE TIMBER/STEEL/GRP

1. Abrade the contact surface with a fine sanding pad, (80/100 grit), removing all dust.
2. Clean the surface with acetone or 100% methylated spirits, using a clean, lint free rag.

PREPARATION OF ALUMINIUM DECKS (PAINTED), BRONZE, BRASS, OR STAINLESS STEEL FITTINGS

1. Clean the substrate with acetone or methylated spirits, using a clean, lint free rag.

PREPARATION OF FITTINGS AND HARDWARE

1. Abrade the contact surface with a fine sanding pad, (180/240 grit), wipe clean with acetone or 100% methylated spirits.

APPLICATION OF MSP 15

1. Apply MSP 15 to the deck, and the fixing screw holes, in a bead of the required thickness. The fitting is then pressed into position
 1. The fixing screws should be tightened sufficiently to pull the fitting down on the space, but no more. Use a plastic spatula to remove the excessive sealant that is proud around the edges. After 24 hours the screws can be tightened.
 2. Traces of uncured MSP 15 can be removed with acetone or methylated spirits. Traces of cured MSP15 can be removed by mechanical methods.

This information has been given in good faith and with the knowledge best known at the time of documentation. It is recommended that due to the differences found in glass that a sample be made before proceeding with the entire job.